

## INDUSTRIAL IONIZING RADIATION

43D MDOS/SGOAM Ext. 4-2571

# Ionizing Radiation, Industrial Strength Overview: Definitions

- <u>Ionizing</u> Vs. <u>Nonionizing</u> Radiation
- X-Rays & Gamma Rays
- Uses in Nondestructive Inspection
- Workplace Exposure & Prevention
- Health Effects
- Monitoring: Dosimeters & OHM Exam


#### III Ionizing Radiation Terms


- Energy transfer that strips electrons off of whatever that energy hits.
- X-Rays: Radiation made by an X-Ray machine using electricity (on / off)
- Gamma Rays: Radiation made by an element source (continual)
  - ex: Iridium 192 and Kryptonite
- Rads, Rems and Sv = units of measure

## Mondestructive Inspection: X-Rays or Gamma Rays

- Examine metal objects: Airplanes, Rockets, welds, casting, forgements.
- Radiation Object Film/Screen
- Result: Two-dimensional 'picture'







## Workplace Radiation Hazards

- Are you safe as long as you don't stand directly in front of the source?
  - NO.
  - Stray radiation ("Scatter")
- Time, Distance, Shielding
  - X-Rays & Gamma Rays
- Electricity
  - X-Ray Machine

#### Preventing Exposure:

- Time, Distance, Shielding
- CONTROLLED AREA
- Operated by Remote Control
  - 75 Feet Away
  - Camera
- Source Capsule "Pig"
- Leaded Apparel: Apron, Gloves, Glasses, Thyroid Shield

#### Health Effects of Radiation

- Target = Rapidly dividing body cells
  - Blood Cells
  - Reproductive Cells
  - Intestinal Cells
  - Thyroid Gland
- Acute Vs Long-Term exposure
  - Radiation Sickness (Acute)
  - Cancer, Cataracts, Birth Defects (Chronic)



#### In Ionizing Radiation: Amount

- How much is considered "acceptable"?
  - Differs with age
  - Differs by body part irradiated
    - Skin of hands
    - Thyroid gland
- Whole Body Dose, Adult: 5 rem/year
- Pregnancy: 0.5 rem/pregnancy
  - Monthly Monitoring
  - 0.05 rem/month

#### Radiation Guidelines

- OSHA, State Laws
- ANSI
- US Nuclear Regulatory Commission
- National Council of Radiation Protection & Measurements
- International Commission on Radiological Protection
- Department of Defense

#### Monitoring: Dosimeters ---

- Quarterly or Monthly Readings
- Worn UNDER Lead Apron/Shield
- Main Type of Dosimeter: TLD (Thermoluminescent Dosimeter)
- Other Types:
  - Pocket Dosimeter Immediate Reading
  - Audible Alarm Dosimeter "Chirper"
  - Film Badge Delayed Reading

## Monitoring: Medica Examinations

- Initial Exam & Past Medical History
- Annual Exam
  - History and Mishap Record
  - Complete Blood Count
  - Eye Exam (Cataracts)
  - Physical: Particularly Skin & Fingertips
- End of Employment Exam

## III Industrial Strength Ionizing Radiation, Summary:

- Definitions
- Uses in Nondestructive Inspection
- Workplace Exposure & Prevention
- Health Effects
  - Chronic Effects
  - Acute Radiation Sickness
- Monitoring: Dosimeters & Exams

# Ionizing Radiation, Industrial Strength Main Points: Time, Distance and Shielding

- Electrocution
- Pregnancy: Notify MD, PH and Supervisor
- Chronic Exposure (Cancers)
- 5 rems/year (0.05 Sv/year)
- Dosimeters and Medical Exams



#### The End

For Additional Information,
Contact the Public Heath
Office
4 - 2751